

LCD Computer Manual:

1. Connect to the power, the machine warm-up for 5 seconds, the screen is all bright and display the current temperature & cartridge change reminder. If the machine no water pressure or water pressure is not

enough, the   will be bright, and the machine with “di---”

alarm; if the machine with normal water pressure, the   will


be bright (Flush for 90 seconds), at the same time, it display the current temperature, the default is °C.

2. When the machine is producing water, the screen display



, the “water producing” display is dynamic frounce, at the same time, water quality display current TDS and working temperature.

3. When the pressure tank is full, the screen is display



and

current water quality; 5 seconds later, the machine is automatically flushing for 8 seconds and then stops working. After water usage, the machine repeat the step 2, after the standby instrument working for 7.5 hours, it will automatically flush for 90 seconds. (repeat)

4. Cartridge change reminder classify for 5 grades, first grade preparative time is about 3 months, (according to the water flow), the small pane of every grade reminder will gradually exhaust along with water usage increase, when the small pane is exhausted, the  will alarm and twinkle remind. After cartridge changing, “Confirm” button restoration, the  will inspect and timing newly.
5. The second grade preparative time is about 6 months, the third grade is about 7- 8 months, the fourth grade is about 36 months, and the fifth is about 18 months, (according to the water quality), the working principle and operation method is same as the step 4.
6. This controller self is with power-off memory system, first use display is Chinese (the default is Chinese display).
7. If press English symbol, twinkle flounce, press “Confirm” button, display confirm is the current choose; If not press the “Confirm” button and press “choose” button, the display is first grade cartridge change remind system twinkle flounce, press the “Confirm” button, the current grade reiteration to Zero, water use memory start newly. And then If not press the “Confirm” button and press “choose” button, the display is second grade cartridge change remind system, it is ordinal until to fifth grade, then press “choose” button, the temperature display method (Fahrenheit F or Centigrade $^{\circ}C$); if not press the “Confirm” button, after 3 seconds the machine automatically enter into working condition state at any condition; and then press “choose” button, the buzzer  is twinkling, press “Confirm” button may choose open or close of the buzzer.
8. Press the “strong flush” button, the machine is automatically flushing for 90 seconds.
9. Water quality  is TDS, the reference quantities of water quality is settled in 25 °C, when the TDS is surpass 50PPM, the machine will alarm and remind.